

Model	Cyl	Year	Crankcase Capacity L	Crankcase Capacity Qt	Engine Oil
100	4	1972- 1973	3.3 L	3.5 Qt	
120	4	1965- 1981	3.3 L	3.5 Qt	
140	4	1973- 1981	3.3 L	3.5 Qt	
2.3L (Ford)	4	1987- 1990	3.8 L	4.0 Qt	
2.5L	4	1982- 1986	3.3 L	3.5 Qt	
3.0L/GL/G S	4	1982- 1998	3.8 L	4.0 Qt	
165	6	1972- 1976	3.8 L	4.0 Qt	
3.8L	6	1981- 1985	3.8 L	4.0 Qt	
4.3L	6	1985- 1998	3.8 L	4.0 Qt	
4.3 HO (Remote Oil Filter)	6	1989-1991	4.0 L	4.2 Qt	
175 (Ford)	8	1975-1977	4.7 L	5.0 Qt	
185 (Ford)	8	1978-1980	3.8 L	4.0 Qt	
190 (Ford)	8	1974- 1977	4.7 L	5.0 Qt	
200	8	1978- 1981	3.8 L	4.0 Qt	
225	8	1972- 1978	4.7 L	5.0 Qt	
230	8	1978- 1981	4.7 L	5.0 Qt	
235	8	1971- 1977	4.7 L	5.0 Qt	
245	8	1972- 1975	4.7 L	5.0 Qt	
250 (Ford)	8	1979	4.7 L	5.0 Qt	

260	8	1978-1981	4.7 L	5.0 Qt	25W40 4-Stroke Synthetic Marine Engine Oil 18-9440-2
262 King Cobra	8	1989	3.8 L	4.0 Qt	
350 King Cobra	8	1986-1989	4.7 L	5.0 Qt	
351 EFI	8	1994-1995	3.8 L	4.0 Qt	
351 King	8	1992	4.7 L	5.0 Qt	
351 King	8	1993	3.8 L	4.0 Qt	
454 HO	8	1991-1993	5.7 L	6.0 Qt	
454 King Cobra	8	1989-1990	5.7 L	6.0 Qt	
460 King Cobr	8	1986-1989	5.7 L	6.0 Qt	
5.0L	8	1986-1996, 1998	4.7 L	5.0 Qt	
5.0L EFI (Ford)	8	1993-1996	4.7 L	5.0 Qt	
502 King Cobra (8.2L)	8	1992-1993	5.7 L	6.0 Qt	
5.7L	8	1982-1985	5.7 L	6.0 Qt	
5.7L/GL/GI	8	1986-1998	4.7 L	5.0 Qt	
5.8L (Ford)	8	1989-1991	4.7 L	5.0 Qt	
5.8L (Ford)/FL/EFI	8	1992-1995	3.8 L	4.0 Qt	
5.8L HO EFI	8	1995	3.8 L	4.0 Qt	
7.4L/GL	8	1988, 1991-1998	5.7 L	6.0 Qt	
7.4L GI	8	1996-1998	7.6 L	8.0 Qt	
7.5L (Ford)	8	1987-1990	4.7 L	5.0 Qt	
8.2L	8	1984-1985	5.7 L	6.0 Qt	

8.2L GSI	8	1998	7.6 L	8.0 Qt	
----------	---	------	-------	--------	--