INSTALLATION INSTRUCTIONS:

- 1. Select an installation position on the boat with minimum deck curvature and where a minimum amount of spray will hit the horn when the boat is underway. Mount the horn facing forward and, whenever possible, at a slight downward angle so that it does not collect water spray.
- 2. At the same time, select an installation position which will assure the shortest possible length of wire from the horn to the 12V power source.
- **3.** Use the horn gasket as a template to mark the location for the two mounting screws and the wire opening. Drill a 7/32" hole through the deck for the wire opening.
- **4.** Insert the wiring through the deck. Use a small amount of silicone sealant to seal the hole and prevent water leaks. Install the gasket and the horn to the deck surface with two #10 pan-head screws of appropriate length.

WIRING INSTRUCTIONS:

- 1. Select the proper stranded wire size from the wiring chart below.
- 2. Cut wires of sufficient length to avoid any tension at connecting points.
- **3.** Connect wiring as illustrated in the diagram. For the best connection, use insulated crimp-on connectors covered with electrical tape.
- **4. Troubleshooting:** Check 5A fuse, check wiring connections and check horn with DC volt meter making sure there are 12 volts across the two horn wires while the horn button is pressed.

RECOMMENDED WIRE SIZES FOR 12 VOLT OPERATION

| Wire Length** | Wire Size | Wire Length** | Wire Size |
|---------------|-----------|----------------|-----------|
| 0-50 feet | 16 AWG* | 0-15 meters | 1.5 mm |
| 51-80 feet | 14 AWG | 16-24 meters | 1.9 mm |
| over 80 feet | 12 AWG | over 24 meters | 2.3 mm |


^{*} AWG: American Wire Gauge

USER SUPPLIED ITEMS REQUIRED FOR INSTALLATION

- Horn button rated for 5 Amps
- 5 Amp fuse and fuse carrier
- #10 size pan-head mounting screws (2)
- Red stranded wire for positive (see Wiring Chart)
- Black stranded wire for negative (see Wiring Chart)
- · Crimp-on wire connectors

BASIC TOOLS REQUIRED FOR INSTALLATION

- Philips-head screwdriver
- Electric drill
- 7/32" drill bit
- Crimping/cutting pliers
- Electrical tape
- Silicone sealant



^{**} As measured from the battery to the horn and back to the battery (round trip).